

SOLIDWORKS®

SOLIDWORKS MBD

Dassault Systèmes SolidWorks Corporation
175 Wyman Street
Waltham, MA 02451 U.S.A.

© 1995-2024, Dassault Systemes SolidWorks Corporation, a Dassault Systèmes company, 175 Wyman Street, Waltham, Mass. 02451 USA. All Rights Reserved.

The information and the software discussed in this document are subject to change without notice and are not commitments by Dassault Systemes SolidWorks Corporation (DS SolidWorks).

No material may be reproduced or transmitted in any form or by any means, electronically or manually, for any purpose without the express written permission of DS SolidWorks.

The software discussed in this document is furnished under a license and may be used or copied only in accordance with the terms of the license. All warranties given by DS SolidWorks as to the software and documentation are set forth in the license agreement, and nothing stated in, or implied by, this document or its contents shall be considered or deemed a modification or amendment of any terms, including warranties, in the license agreement.

For a full list of the patents, trademarks, and third-party software contained in this release, please go to the Legal Notices in the SOLIDWORKS documentation.

Restricted Rights

This clause applies to all acquisitions of Dassault Systèmes Offerings by or for the United States federal government, or by any prime contractor or subcontractor (at any tier) under any contract, grant, cooperative agreement or other activity with the federal government. The software, documentation and any other technical data provided hereunder is commercial in nature and developed solely at private expense. The Software is delivered as "Commercial Computer Software" as defined in DFARS 252.227-7014 (June 1995) or as a "Commercial Item" as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in Dassault Systèmes standard commercial end user license agreement. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov. 1995) or FAR 52.227-14 (June 1987), whichever is applicable. The terms and conditions of the Dassault Systèmes standard commercial end user license agreement shall pertain to the United States government's use and disclosure of this software, and shall supersede any conflicting contractual terms and conditions. If the DS standard commercial license fails to meet the United States government's needs or is inconsistent in any respect with United States Federal law, the United States government agrees to return this software, unused, to DS. The following additional statement applies only to acquisitions governed by DFARS Subpart 227.4 (October 1988): "Restricted Rights - use, duplication and disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252-227-7013 (Oct. 1988)."

In the event that you receive a request from any agency of the U.S. Government to provide Software with rights beyond those set forth above, you will notify DS SolidWorks of the scope of the request and DS SolidWorks will have five (5) business days to, in its sole discretion, accept or reject such request. Contractor/ Manufacturer: Dassault Systemes SolidWorks Corporation, 175 Wyman Street, Waltham, Massachusetts 02451 USA.

Contents

Introduction

About This Course	2
Prerequisites	2
Using this Book	2
Conventions Used in this Book	3
About the Training Files	3
Training Templates	4
Windows OS	5
Graphics and Graphics Cards	5
Setting up SOLIDWORKS MBD	5
Accessing Commands	6
More SOLIDWORKS Training Resources	6
Local User Groups	6

Lesson 1:

Introduction to SOLIDWORKS MBD

What is SOLIDWORKS MBD?	8
Course Layout	8
MBD using Feature Dimensions	9
Annotations Folder	9
Annotations Views	10
3D Views	12
Sharing 3D Views	13
3D PDFs	13

3D PDF Capabilities	14
Viewport Types	14
Viewport Toolbar	14
Markup Capabilities	15
MBD using DimXpert	16
DimXpert Capabilities	17
eDrawings and MBD	17
eDrawings Capabilities	18
STEP 242 Files	18
MBD and Assemblies	19
Assemblies in 3D PDFs	20
Steps in the Process	22

Lesson 2:

Using Feature Dimensions and Annotation Views

Using Feature Dimensions with MBD	24
Default Annotation Views	24
Optimizing Settings	25
Using Templates	28
Customizing the CommandManager	30
Adding and Organizing Annotations	30
Activating a Annotation View	31
Annotation Views Shortcut menu	31
Adding Reference Dimensions	32
Annotation View Assignment	34
Modifying Dimensions	35
Creating a Section Annotation View	38
Editing an Annotation View	39
Unassigned Items	40
Creating an Annotation View	41
Notes Area	44
Show on Open	44
Design Library Notes	45
Using Tables	47
Title Block Table	47
Sharing a Model	49
Exercise 1: Main Body Annotation Views	51
Exercise 2: Adding Notes and Tables	62
Exercise 3: Flange Annotation Views	65
Exercise 4: Fork Annotation Views	67

Lesson 3: Capturing 3D Views

3D Views	70
3D Views Tab	70
Capture 3D View	71
Activating and Modifying 3D Views	74
Using 3D Views Options	75
Dynamic Annotation Views	75
Publishing PMI	77
Publish to 3D PDF	77
Publish to eDrawings	80
STEP242 Files	83
Special 3D View Types	84
Detail Views	84
Auxiliary Views	85
Section Views	85
Broken Views	87
Model Break View	87
Accessing Model Break Views	89
Exercise 5: Main Body 3D Views	93
Exercise 6: Publishing PMI	96
Exercise 7: Broken-out Section and Break Views	102
Exercise 8: Auxiliary View	106

Lesson 4: 3D PDF Template Editor

3D PDF Template Editor	112
Areas of the Template	113
Logo Images	113
Comments and Custom Properties Area	114
Table	114
Static Notes	114
Primary Viewport	114
Thumbnail Area	114
Pages Tabs	114
Text Types	114
Other Template Aspects	115
Borders and Backgrounds	115
Page Setup	116
Independent Viewport	116
Projected Viewport	116

Building a Custom Template	116
Modifying Template Text.....	119
Adding Imported Notes	123
Saving and Storing Custom Templates.....	127
3D PDF Theme File Location.....	128
Testing the Template.....	129
Supplemental Tutorials.....	131
Exercise 9: Create the 3D PDF Part Template	132

Lesson 5: Using DimXpert

What is DimXpert?.....	140
DimXpert Settings	140
DimXpert Block Tolerances	142
Block Tolerance	142
General Tolerance.....	142
General Block Tolerance	143
DimXpert Dimension Settings	144
Size Dimensions	144
Location Dimension	145
Chain Dimension	145
Geometric Tolerance.....	145
Chamfer Controls	145
Display Options	145
How DimXpert Works	148
Auto Dimension Scheme	149
DimXpertManager	150
Linked Features.....	150
Tree Display	151
Tolerance Status	151
Show Tolerance Status	152
Modifying DimXpert Annotations	152
DimXpert Annotation Views	152
DimXpert Locations	153
Combining Dimensions	156
Creating Multiple Schemes.....	157
Copy Scheme	158
Manual DimXpert Annotations.....	158
Feature Selector Toolbar.....	158
Default DimXpert Features.....	158
Intersection and Compound Features	161
Collection Pattern Feature	163

Using DimXpert Dimension Tools	164
DimXpert Dimension Types	165
Unique DimXpert Options	172
Linear or Angular Dimension	173
Reference Features	174
DimXpert Direction	174
Supplemental Tutorials	175
Exercise 10: Auto Dimension Scheme	176
Exercise 11: Multiple Schemes	182
Exercise 12: Manual DimXpert Annotations	191
Automating Basic Dimensions	194

Lesson 6:

MBD and Assembly Models

Assembly Models and MBD	198
Assembly Level Dimensions	198
Optimizing Settings in Assemblies	200
Additional Settings to Consider	200
Adding Assembly Annotations	202
BOM Tables and Balloons	204
Publishing Assembly PMI	207
Additional MBD Tools	211
Supplemental Tutorials	212
Exercise 13: Assembly Annotations	213
Modifying Font Size	215
Exercise 14: Assembly Exploded Views	221